

Morrifield Screen Door Installation

Tools Required

Drill & 5mm drill bit

Hammer

Phillips head screwdriver

Pencil / Pen

Ruler / Tape measure

Hacksaw

1. Remove door and current top door track. (Do not leave the door in direct sunlight or somewhere it may blow over). *It may be necessary to cut 5mm off the top of the existing doors' wheel hangers so it can fit in the box section of the new door-track.*
2. Attach the short length of bottom door track to the left side of the existing door track using the supplied nails.
3. Mark 300mm centre on the top door-head (between door frames). Mark centre of new top door track.
4. Remove end screw and fit 1 door into the new door-track. Place the supplied wooden spacer in the bottom door-track & sit the door into the bottom track. Ensure the door track is centered and drill all the way through the door-track and arch towards both ends of the track. Take care not to puncture the cover when the drill comes through the inside of the arch.
5. Attach door-track to frame using long bolts. The nylon washers go between the track and the frame.
6. Remove spacer from bottom track and install 2nd door, ensuring that screen door goes on the left and the polythene door is on the right.

